



3.0 Gallons

2.0 Gallons

1.5 Gallons

1.0 Gallon

## ECONO SERVERS WITH LEVEL INDICATOR



3.0 Gallons

2.0 Gallons

1.5 Gallons









1.0 Gallon

## ECONO SERVERS WITH SIGHT GAUGE

# SPARE PARTS CATALOG

# ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE

## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE

ITEM #	IMAGE	DESCRIPTION	UM
<b>ECONO Server with Level Indicator Parts</b>			
109047		Faucet Body Assembly, No Gauge [All dispensers with level indicators]	1  EA.
109086		Label, Level Indicator Capacity [All dispensers with level indicators]	1  EA.
109129		Retaining Clip, "D" Shape [All dispensers with level indicators]	1  EA.
109379		Label, Dispenser Gauge Hole [All dispensers with level indicators]	1  EA.
109974		Server, SS 1.0 Gallon Level Indicator	1  EA.
109975		Server, SS 1.5 Gallon Level Indicator	1  EA.
109976		Server, SS 2.0 Gallon Level Indicator	1  EA.
109977		Server, SS 3.0 Gallon Level Indicator	1  EA.









## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE

ITEM #	IMAGE	DESCRIPTION	UM	UM
<b>ECONO Server with Level Indicator Parts - Continued</b>				
110717		Bonnet Kit, Orange/Green	1	EA.
111958		Washer, 3/4" External Tooth SS	1	EA.
112000		Clamp, Snap Grip .68" - .81"	1	EA.
109056		Lid Assembly, Level Indicator 1.0 Gallon	1	EA.
109057		Lid Assembly, Level Indicator 1.5 Gallon	1	EA.
109058		Lid Assembly, Level Indicator 2.0 Gallon	1	EA.
109059		Lid Assembly, Level Indicator 3.0 Gallon	1	EA.

## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE

ITEM #	IMAGE	DESCRIPTION	UM	UM
<b>ECONO Server with Sight Gauge</b>				
109927		Coffee Server. SS 1 Gallon	1	EA.
109975		Coffee Server, SS 1.5 Gallon Level Indicator	1	EA.
109992		Coffee Server. SS 2.0 Gallon	1	EA.
109993		Coffee Server. SS 3.0 Gallon	1	EA.
109367		Lid, Assembly No Level Indicator 1.5 Gallon [Also used on the 1.0 gallon, 2.0 gallon & 3.0 gallon servers]	1	EA.
111946		Faucet, 1 Gallon Econo Red Handle	1	EA.
111947		Faucet, 1.5 Gallon Econo Red Handle	1	EA.
111948		Faucet, 2.0 Gallon Econo Red Handle	1	EA.

## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE

ITEM #	IMAGE	DESCRIPTION	UM
<b>ECONO Server with Sight Gauge - Continued</b>			
111949		Faucet, 3.0 Gallon Econo Red Handle	1 EA.
109097		Label, No Level Indicator [1.0 gallon, 1.5 gallon, 2.0 gallon servers only]	1 EA.
110717		Bonnet Kit, Orange/Green	1 EA.
109098		Seal, Spiral No Level Indicator	1 EA.
112000		Clamp, Snap Grip .68" - .81"	1 EA.
111950		Label, Volume 1 Gallon Econo	1 EA.
111951		Label, Volume 1.5 Gallon Econo	1 EA.
111952		Label, Volume 2.0 Gallon Econo	1 EA.

## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE

ITEM #	IMAGE	DESCRIPTION	UM	UM
<b>ECONO Server with Sight Gauge - Continued</b>				
111953		Label, Volume 3.0 Gallon Econo	1	EA.
111958		Washer, 3/4" External Tooth SS	1	EA.
706352		Screw, 6-32 x 3/8" PTHMS [Used on all servers with sight gauge]	1	EA.
<b>Bonnet Assembly Replacement Parts For Both Servers Series</b>				
700612		Bonnet Assembly, Faucet – Red	1	EA.
700613		Bonnet Assembly, Faucet – Black	1	EA.
700334		Bonnet Only, Faucet – Red	1	EA.
700614		Bonnet Only, Faucet – Black	1	EA.
700327		Handle Only, Faucet - Red	1	EA.

## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE









ITEM #	IMAGE	DESCRIPTION	UM	UM
<b>Bonnet Assembly Replacement Parts For Both Servers Series - Continued</b>				
701283		Handle Only, Faucet – Black	1	EA.
700407		Spring, Faucet	1	EA.
700408		Stem, Faucet	1	EA.
700409		Seat Cup, Faucet	1	EA.
<b>Replacement Parts For Faucet With Sight Gauge</b>				
109001		*Faucet Body, Insulated Gauge [1.0 Gal,1.5 Gal ,2.0 Gal, 3.0 Gal]	1	EA.
NA		*Plastic Nut For Faucet Body [This nut is part of the faucet body, it does not have a part number]	1	EA.
109028		Sight Gauge, Plastic 1.0 Gallon	1	EA.
109033		Plastic Glass Shield, 1.0 Gallon	1	EA.



## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE


ITEM #	IMAGE	DESCRIPTION	UM	UM
<b>Replacement Parts For Faucet With Sight Gauge. - Continued</b>				
109038		Insert, Plastic Glass Shield, 1.0 Gallon	1	EA.
110609		Plastic Sleeve, .375" ID x .531" OD [1.0 Gal,1.5 Gal ,2.0 Gal, 3.0 Gal]	1	EA.
110663		Cap, Plastic Glass Shield – Black [1.0 Gal,1.5 Gal ,2.0 Gal, 3.0 Gal]	1	EA.
110668		Nut, Black Plastic [1.0 Gal,1.5 Gal ,2.0 Gal, 3.0 Gal]	1	EA.
110672		O-Ring, 3/8" ID x .103 [1.0 Gal,1.5 Gal ,2.0 Gal, 3.0 Gal]	1	EA.
109029		Sight Gauge, Plastic 1.5 Gallon	1	EA.
109034		Plastic Glass Shield, 1.5 Gallon	1	EA.
109039		Insert, Plastic Glass Shield, 1.5 Gallon	1	EA.

## ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE


ITEM #	IMAGE	DESCRIPTION	UM	UM
<b>Replacement Parts For Faucet With Sight Gauge. - Continued</b>				
109036		Plastic Glass Shield, 2.0 Gallon	1	EA.
109041		Insert, Plastic Glass Shield, 2.0 Gallon	1	EA.
110673		Sight Gauge, Plastic 2.0 Gallon	1	EA.
109032		Sight Gauge, Plastic 3.0 Gallon	1	EA.
109037		Plastic Glass Shield, 3.0 Gallon	1	EA.
109042		Insert, Plastic Glass Shield, 3.0 Gallon	1	EA.
109002		Faucet Body Adaptor [1.0 Gal,1.5 Gal ,2.0 Gal, 3.0 Gal]	1	EA.
109003		Gauge Adaptor [1.0 Gal,1.5 Gal ,2.0 Gal, 3.0 Gal]	1	EA.

# ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE


## Additional Pictures:




111950, Volume Label  
1.0 Gallon - Econo



111951, Volume Label  
1.5 Gallon - Econo



111952, Volume Label  
2.0 Gallon - Econo



111953, Volume Label  
3.0 Gallon - Econo



109086, Label Level Indicator –  
Capacity [Used on the lid assembly]



109097, Label No Level Indicator  
[Used on the lid assembly]



109379, Label Sight Gauge Hole  
[Used to cover up hole located on the  
front of the dispenser if not a sight  
gauge dispenser]



### Faucet Kit Assembly with Sight Gauge

PN: 111946, Faucet Assembly 1 Gallon Red Handle

PN: 111947, Faucet Assembly 1.5 Gallon Red Handle

PN: 111948, Faucet Assembly 2.0 Gallon Red Handle

PN: 111949, Faucet Assembly 3.0 Gallon Red Handle

# ECONO SERVERS WITH LEVEL INDICATOR OR SIGHT GAUGE

## Additional Pictures:



### Server Used In the Econo Dispenser Series

- PN: 109974, Server SS 1.0 Gallon [Level Indicator Lid Assembly]
- PN: 109975, Server SS 1.5Gallon [Level Indicator Lid Assembly]
- PN: 109976, Server SS 2.0 Gallon [Level Indicator Lid Assembly]
- PN: 109977, Server SS 3.0 Gallon [Level Indicator Lid Assembly]
- PN: 109927, Coffee Server SS 1.0 Gallon [Sight Gauge & Lid without Level Indicator]
- PN: 109975, Coffee Server SS 1.5 Gallon [Sight Gauge & Lid without Level Indicator]
- PN: 109992, Coffee Server SS 2.0 Gallon [Sight Gauge & Lid without Level Indicator]
- PN: 109993, Coffee Server SS 3.0 Gallon [Sight Gauge & Lid without Level Indicator]



### Lid Assemblies Used In the Econo Dispenser Series

PN: 109367, Lid Assembly, No Level Indicator  
[Used with Econo Server with Sight Gauge – 1.0, 1.5, 2.0, 3.0 Gallon]

PN: 109056, Lid Assembly with Level Indicator – 1.0 Gallon

PN: 109057, Lid Assembly with Level Indicator – 1.5 Gallon

PN: 109058, Lid Assembly with Level Indicator – 2.0 Gallon

PN: 109059, Lid Assembly with Level Indicator – 3.0 Gallon

