

PN 782389_02102012

NEWCO
ENTERPRISES, INC.



**OPERATION MANUAL
NEWCO'S MODEL CX-TOUCH W/QR CODE
SPECIALTY DRINK SINGLE CUP BREWER
WITH AUTO EJECT SYSTEM**


3650 NEW TOWN BLVD. ST. CHARLES MO 63301 WWW.NEWCOCOFFEE.COM 1.800.325.7867

Table of Contents

Machine Labels	Page: 3
Introduction & NEWCO Product Warranty	Page: 4
Machine Dimensions & Specifications	Page: 5
Machine Features	Page: 7
Plumbing connections	Page: 8
Electrical Hook-Up	Page: 8
Installation Instructions	Page: 9
Set-Up Instructions	Page: 10
Brewing and beverage selections	Page: 12
Programming Instructions	Page: 14
Custom Logo-Wi-Fi Setup	Page: 15
Install Custom Logo	Page: 16
Service Notes & Troubleshooting	Page: 18
QR Code Brewing Instructions	Page: 19
Machine Access Points	Page: 20
Pod Brew Mechanism Removal	Page: 21
Whipper Assembly	Page: 22
Tank Assembly [780048]	Page: 23
Whipper & Cannister Assembly	Page: 24
Brew Mechanism Assembly [780052 – 61MM]	Page: 25
Wiring Diagram	Page: 26

Warning Labels

NOTICE: Read and follow all notices posted on this machine.
Do not damage or destroy these notices as they are for your protection



Introduction & Newco Product Warranty

INTRODUCTION

This machine is intended to brew 8-12-ounce single serving of coffee and / or powdered hot drinks into a cup. This machine will also dispense hot water for allied beverage use. It is intended for indoor use only on a sturdy counter or shelf.

**Newco warrants equipment manufactured by it for 1-year parts and labor.
Accessories and Dispensers 1 Year parts only.
Electronic Circuit and Control Boards- 3 years parts, 1-year labor.
Equipment manufactured by others and distributed by Newco-please see
original equipment manufacturers warranty, Newco will follow.**

These warranty periods run from the date of sale Newco warrants that the equipment manufactured by it will be commercially free of defects in material and workmanship existing at the time of manufacture and appearing within the applicable warranty period. This warranty does not apply to any equipment, component or part that was not manufactured by Newco or that, in Newco's judgment, has been affected by misuse, neglect, alteration, improper installation or operation, relocation or reinstallation, improper maintenance or repair, incorrect voltage applied to the unit at any time, damage or casualty. This warranty does not apply to any equipment failures related to poor water quality, excessive lime and chlorine and non-periodic cleaning and descaling. Warranty is null and void if muriatic or any other form of hydrochloric acid is used for cleaning or deliming. In addition, this warranty does not apply to replacement of items subject to normal use including but not limited to user replaceable parts such as faucet seat cups, sight gauge tubes, washers, O-rings, tubing, seals and gaskets.

This warranty is conditioned on the Buyer 1) giving Newco prompt notice of any claim to be made under this warranty by telephone at (800) 556-3926 or by writing to 3650 New Town Blvd, Saint Charles, MO 63301; 2) if requested by Newco, shipping the defective equipment prepaid to an authorized Newco service location; and 3) receiving prior authorization from Newco that the defective equipment is under warranty.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTY, WRITTEN OR ORAL, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF EITHER MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. The agents, dealers or employees of Newco are not authorized to make modifications to this warranty or to make additional warranties that are binding on Newco. Accordingly, statements by such individuals, whether oral or written, do not constitute warranties and should not be relied upon.

If Newco determines in its sole discretion that the equipment does not conform to the warranty, Newco, at its exclusive option while the equipment is under warranty, shall either 1) provide at no charge replacement parts and/or labor (during the applicable parts and labor warranty periods specified above) to repair the defective components, provided that this repair is done by a Newco Authorized Service Representative; or 2) shall replace the equipment or refund the purchase price for the equipment.

THE BUYER'S REMEDY AGAINST NEWCO FOR THE BREACH OF ANY OBLIGATION ARISING OUT OF THE SALE OF THIS EQUIPMENT, WHETHER DERIVED FROM WARRANTY OR OTHERWISE, SHALL BE LIMITED, AT NEWCO'S SOLE OPTION AS SPECIFIED HEREIN, TO REPAIR, REPLACEMENT OR REFUND.


In no event shall Newco be liable for any other damage or loss, including, but not limited to, lost profits, lost sales, loss of use of equipment, claims of Buyer's customers, cost of capital, cost of down time, cost of substitute equipment, facilities or services, or any other special, incidental or consequential damages.

Machine Dimensions & Specifications

120 VAC-1700W HEATER-15A USA POWER SUPPLY


1 GALLON TANK 8-12 OZ CUP SIZE TEMPERATURE RANGE 180-205F

Machine Functions



Machine Dimensions & Specifications – Continued

FRONT VIEW



Machine Features

- **TOUCH SCREEN DISPLAY**
- **FACTORY CALIBRATED-PLUG & PLAY**
- **AUTOMATED POD DRAWER**
- **AUTOMATIC POWDER LEVEL RESET OPTION**
- **POD DRAWER COUNT & COUNT RESET**
- **88 PRE-PROGRAMMED DRINKS AVAILABLE**
- **WHIPPER RINSE BUTTON**
- **INDEPENDENT POWDER HOPPER COUNTDOWN & RESET OPTION**
- **CUSTOM CALL FOR SERVICE NUMBER OPTION**
- **POWER SAVE & POWER DOWN OPTION**
- **WATER FILTER MONITORING OPTIONS**
- **POD WASTE DRAWER SENSOR**
- **POD AUTO EJECTION SYSTEM**
- **CUP BREW LED LIGHT**
- **PUSH & HOLD HOT WATER BUTTON**
- **COFFEE VOLUME FLOWMETER CONTROL**
- **DUMP VALVE DELIVERY FOR POWDERS**

THIS MACHINE IS FACTORY CALIBRATED AND IS CONFIGURED AND READY TO DISPENSE 8 OUNCE DRINKS. TO CHANGE RECIPES, SEE PROGRAMMING SECTION, MACHINE SET-UP.

Plumbing Connections

This machine must be connected to a cold-water system with operating pressure between 20 and 90 psi (138 and 620 kPa) from a 1/2" or larger supply line. A shut-off valve should be installed in the line before the machine. Install a regulator in the line when pressure is greater than 90 psi (620 kPa) to reduce it to 50 psi (345 kPa). The water inlet fitting is 1/4" flare.

NOTE –Newco recommends 1/4" copper tubing for installations of less than 25 feet and 3/8" for more than 25 feet from the 1/2" water supply line. A tight coil of copper tubing in the water line will facilitate moving the machine to clean the countertop. Newco does not recommend the use of a saddle valve to install the brewer. The size and shape of the hole made in the supply line by this type of device may restrict water flow.

This equipment must be installed to comply with the Basic Plumbing Code of the Building Officials and Code Administrators International, Inc. (BOCA) and the Food Service Sanitation Manual of the Food and Drug Administration (FDA). For models installed outside the U.S.A., comply with the applicable Plumbing /Sanitation Code.

Flush the water line and securely attach it to the inlet fitting at the rear of the brewer.

Turn on the water supply and check for leaks.

Plumber's Installation Instructions

CAUTION: Disconnect Power to machine before proceeding with plumbing installation.

- 1) Attach water line to water filter, rear of machine.
- 2) Flush water line before installing machine. Machine should be connected to COLD WATER LINE ONLY.
- 3) Water pressure should be at least 40 lbs. For less than a 25 ft run, use 1/4" copper tubing and connect to 1/2" or larger water line. For longer runs, use 3/8" copper tubing & connect to 1/2" or larger water line and provide an adapter fitting for connection to the brewer. **A dedicated water line is necessary for this machine.**
- 4) If installed with saddle valve, the valve should have a minimum of 1/8" porthole for up to 25 ft run, and 5/16" porthole for over 25 ft runs.
- 5) **Manufacturer recommends connecting to copper tubing.**

Electrical Hook-Up

WARNING

The brewer must be disconnected from the power source until specified in Installation Instructions.

Determine the available on-site electrical requirements.

Refer to Data Plate on the Brewer, and local/national electrical codes to determine circuit requirements.

CAUTION – Improper electrical installation will damage electronic components.

Installation Instructions

WARNING: - Read and follow installation instructions before plugging or wiring in machine to electrical circuit. Warranty will be void if machine is connected to any voltage other than that specified on the nameplate serial tag.

- 1) Machine must be on a flat and level surface. Plug or wire in machine to appropriate voltage as noted on the brewer serial tag. Serial tag is located on side of machine.
- 2) With water line connected, turn machine power ON (power switch located lower right rear of machine). Install Drip tray and drip tray grate under brew area (slide tray between guide rails until seated).
- 3) Tank will automatically fill, and machine will start heating. If tank does not fill in 8 minutes, a “tank fill error” will occur. (Note: To reset error power machine on/off with power switch).
- 4) Allow 10 to 15 minutes for water in tank to heat to brewing temperature. (Additional water may drip into drip tray on initial expansion of water in the tank). This will not occur thereafter.
- 5) Heater will turn on when water in tank is at probe level. If brew is initialized before tank temperature is reached, machine will display “Preparing to Brew” until temp is reached, then will start brewing.
- 6) **In higher altitude locations (3000 feet above sea level) the thermostat may have to be adjusted lower to prevent boiling:**

Brew water temperature is factory set at 200o F (92.3o C) Areas of high altitude will require lowering this temperature to prevent boiling. This chart should be used as a guide when readjusting the brew water temperature.		
Altitude (Feet)	Boiling point of water o F o C	Recommended water temperature o F o C
-1000	213.8 101.0	200 93.3
-500	212.9 100.5	200 93.3
0	212.0 100.0	200 93.3
500	211.1 99.5	200 93.3
1000	210.2 99.0	200 93.3
1500	209.3 98.5	200 93.3
2000	208.4 98.0	200 93.3
2500	207.4 97.4	200 93.3
3000	206.5 96.9	199 92.8
3500	205.6 96.4	198 92.2
4000	204.7 95.9	197 91.7
4500	203.8 95.4	196 91.1
5000	202.9 94.9	195 90.6
5500	201.9 94.4	195 90.6
6000	201.0 93.9	194 90.0
6500	200.1 93.4	193 89.4
7000	199.2 92.9	192 88.9
7500	198.3 92.4	191 88.3
8000	197.4 91.9	190 87.8
8500	196.5 91.4	189 87.2
9000	195.5 90.8	188 86.7
9500	194.6 90.3	187 86.1
10000	193.7 89.8	186 85.6

Set up instructions for CX TOUCH Machine

CX Touch, battery-less units operate differently than older units that contain batteries in the tablet. It is no longer necessary or desirable to use the power switch on the tablet display. The display will power on and off with the brewer automatically. Note that since the tablet does not contain a battery, the tablet will go through a bootup sequence any time the power is cycled to the brewer.

Note: This machine is designed to be run with power turned on at all times.

Machine Startup Instructions

Fill and install 2lb hoppers with nozzles turned up, Chocolate on left and Milk on right. Make sure “button” on bottom of hopper is seated in slot in sheet metal. Slight manual rotation of the auger gear may be necessary to seat hopper in correct location. Rotate dispense nozzles down into whipper bowl.


Ensure that there is a proper water supply connected to the machine and water is turned on. Ensure that the machine is plugged into a proper power outlet and there is power supplied to the machine. Turn machine power switch on, machine should start filling, will shut off when full. The Touch Screen Display will indicate when the machine is filling.

Heater will turn on when water in tank is at probe level and will display Heating: Please Wait. The heating process can take 10-15 minutes before the machine is ready to brew.

When machine temperature reaches brew temp, display will change to the Drink Instruction Screen. The machine is now ready for operation.

Touching the screen will bring up the Drinks Menu Selection Screen


Place an empty cup in the brewing area, open the powdered hopper door, and depress the “Rinse” button next to the whipper bowl until the water runs clear.



Brewing Drinks



To dispense a drink, place a cup under the dispense area, press a brew selection and place a pod flat side up (not necessary if the drink selection does not use a pod)

Once a selection is made a Submenu for Drink Settings will appear-see page 13



ICED DRINKS ARE SIZED FOR CUP TO BE PRE-FILLED WITH 2/3 CUP OF ICE

Drinks Submenus







Programming Instructions



TAP 3 TIMES TO ENTER PROGRAMMING MODE

IF A BREWING ICON IS ACCIDENTLY TOUCHED USE THE RETURN ARROW TO TRY AGAIN

Screen will change to Program Menu Screen:



Water Temperature --180 - 203 Deg F	Powder Tracking --Toggle Powder Tracking On-Off
Waste Bin Size--OFF , 2-50	Set DC Pump Speed , 1-87
Air Blow Strength--3-10	Energy Save Mode--OFF, SEMI, FULL
Air Blow Time--2-15 seconds	Energy Save Time--Timer from last dispense till Energy Save kicks in
Water Filter Size--OFF , 500-3000 Gallons	Default Cup Size--Sets Cup Size displayed As Default
Call For Service #--# will be shown on "Call for Service " Screens	Drink Selection Menu--See Below
Exit Setup Mode	Restore Factory Settings

Water Filter Remaining Gal*
***NOT SHOWN IF NOT USING A WATER FILTER**

Water filter Reset--Select this after changing filters to reset water filter countdown*

Whipper Seal Remaining--Remaining powdered drink cycles before changing the Whipper Seal

Whipper Seal Reset--Reset count after changing Whipper Seal

Exit Maintenance Mode

Total run cycles--Total drinks dispensed

Pod brew cycles--Tea & Coffee drinks dispensed

Total Water Usage--Total Gallons of water dispensed*

Waste Bin Contents --Used Pods in Bin

Chocolate Grams Remain--Chocolate grams remaining in Hopper**

Milk Grams Remain--Milk grams remaining in Hopper**

Exit Statistics Mode

****NOT SHOWN IF POWDER TRACKING IS DISABLED**

Primary Newco Server (Future Use)


Secondary Server (Future Use)

Sleep Timeout--time brewer will stay awake before entering sleep screen

Brewing Screen--Toggles between Slates & Movies or display Installed Logo Screen

Install Logo & Load Software Update *See Page 16

Exit Local Setup Mode



Drink Selection Menu

Ability to turn Drink Selections and/or Cup Sizes On or Off

Exit Drink Selection Mode

Custom Logo--Wi-Fi Setup

SETTING UP A CUSTOM LOGO SCREEN REQUIRES A WI-FI CONNECTION TO THE CX-TOUCH MACHINE.
NOTE THAT AFTER THE LOGO IS INSTALLED, THE WI-FI CONNECTION MUST BE TURNED BACK TO "OFF" STATUS.
UPDATES THAT MAY OCCUR IF WI-FI IS LEFT ON WILL CAUSE OPERABILITY ISSUES WITH THE BREWER.



ACCESS THE BREW SELECTION SCREEN



TAP THE "TEA & WATER" BAR 3 TIMES TO ENTER PROGRAMMING MODE. - IF A BREWING ICON IS ACCIDENTLY TOUCHED USE THE RETURN ARROW TO TRY AGAIN

SELECT LOCAL SETUP FROM PROGRAMMING MENU AND THEN CHOOSE NETWORK SETUP. THIS WILL TAKE YOU TO THE ANDROID SETTINGS SCREEN WHERE YOU WILL BE ABLE TO CONNECT TO WI-FI NETWORK.

SELECT WI-FI FROM THE SETTINGS SCREEN. TURN WI-FI ON. SELECT THE NETWORK WHEN IT APPEARS. ENTER THE PASSWORD AND CONNECT.



ONCE CONNECTED, YOU WILL NEED TO TURN POWER TO THE BREWER OFF AND THEN BACK ON AGAIN TO EXIT THE ANDROID SETTINGS MENU AND RETURN TO THE CX PROGRAMMING SCREENS. POWER SWITCH IS ON THE LOWER RIGHT REAR OF BREWER. WHEN THE TABLET REBOOTS, ENTER THE LOCAL SETUP SCREEN AS DESCRIBED AT LEFT.

CHOOSE INSTALL LOGO



THIS ADDRESS IS UNIQUE FOR EVERY MACHINE. NOTE THAT IT IS USED FOR THE HOST ADDRESS WHEN SETTING UP COMMUNICATION WITH ANOTHER DEVICE TO TRANSFER LOGO (SEE NEXT PAGE).

Install Logo Instructions-Custom Sleep Screen (IOS Apple Version)

INSTALL THE "ITRANSFER" APP ONTO A LOCAL PHONE OR TABLET. CONNECT THE LOCAL PHONE OR TABLET TO THE SAME WIFI NETWORK AS THE CX-TOUCH.


APPLICATION EXAMPLE SHOWN IS "ITRANSFER"

FOR I-PHONE/IOS/APPLE

SETUP FTP CONNECTION AS SHOWN-COPY HOST ADDRESS FROM CX-TOUCH AS SHOWN ON SCREEN-
NOTE-EACH MACHINE HAS A UNIQUE ADDRESS

PASSWORD IS ftp




1. OPEN THE APP AND SLELCT FTP/FTPS/ SFTH, ADD SERVER,



2. FOR SERVER NAME ENTER CX




3. FOR HOST IP ADDRESS COPY IP ADDRESS INFO FROM CX-TOUCH

4. FOR REMOTE PATH INFO ENTER - /data/data/com.newcocolatee.cx3/cache




5. ENTER PORT 2121, USERNAME ftp, PASSWORD ftp THEN SAVE-SERVER NAME IS NOW SHOWN AS CX

6. TAP SERVER CX TO CONNECT TO CX-TOUCH MACHINE




Install Logo Instructions-Custom Sleep Screen (IOS Apple Version) Cont'd


7. STATUS ON CX-TOUCH MACHINE CHANGES TO Connected-Waiting for transfer




8. TO SELECT A FILE TO TRANSFER SELECT THE UPLOAD BUTTON



9. SELECT THE DIRECTORY WHERE THE IMAGE FILE TO BE TRANSFERRED RESIDES




10. SELECT THE IMAGE TO BE TRANSFERRED THEN SELECT Upload



11. FILE WILL TRANSFER TO THE CX-TOUCH MACHINE



12. SELECT FINISH TO COMPLETE TRANSFER, THEN EXIT FROM PROGRAMMING SCREENS. TURN OFF WI-FI, SEE BELOW.




Turning off WI-FI Mode – MUST FOLLOW THIS PROCEDURE

TAP THE "TEA & WATER" BAR 3 TIMES TO ENTER PROGRAMMING MODE. - IF A BREWING ICON IS ACCIDENTLY TOUCHED USE THE RETURN ARROW TO TRY AGAIN



SELECT LOCAL SETUP FROM PROGRAMMING MENU AND THEN CHOOSE NETWORK SETUP. THIS WILL TAKE YOU TO THE ANDROID SETTINGS SCREEN WHERE YOU WILL BE ABLE TO DISCONNECT FROM THE WI-FI



SELECT WI-FI FROM THE SETTINGS SCREEN. TURN WIFI OFF.

ONCE DISCONNECTED, YOU WILL NEED TO TURN POWER TO THE BREWER OFF AND THEN BACK ON AGAIN TO EXIT THE ANDROID SETTINGS MENU AND RETURN TO NORMAL CX OPERATION. POWER SWITCH IS ON THE LOWER RIGHT REAR OF BREWER. THE TABLET WILL REBOOT AND ENTER THE CX APPLICATION FOR NORMAL BREWER OPERATION.

Service Notes & Troubleshooting



These error screens will display a service phone number to call if entered in “Setup” Menu (Page 15)

*Usually repairing a bad connection or replacing the indicated motor will remedy the problem.

Display Reads	Possible Cause(s)	Remedies	Notes
Fill Timeout Error	Water shut off to Machine	Check Water Supply Shutoff	Initial fill time longer than 8 minutes
	Supply Line Blocked or too small	Repair or Replace as needed	Fill time Longer than 1 Minute
	Water Filter Restricted	Replace-Service Required	Water Probe has a 30 second Hysteresis cycle
	Inlet Solenoid valve Faulty	Replace-Service Required	
	Control Board Failure	Replace-Service Required	
Thermistor Error	Thermistor not plugged in	Make sure plug-in housing is latched	Open or Shorted Thermistor
	Faulty Thermistor	Replacement	
	Control Board Failure	Replace-Service Required	
Heater Error	Faulty Thermistor	Replacement	4 Minute Continuous Heater Run
	Faulty Heater Element	Replace-Service Required	
	Control Board Failure	Replace-Service Required	
Motor Errors*	Wiring Disconnect Brew Mech	Check Brew Mech Wires, Harness	

DRAINING THE HOT WATER TANK

THE DRAIN TUBE IS CLIPPED TO THE TANK PLATE IN FRONT OF THE TANK. TANK HOLDS APPROX 1 US GALLON. THE HOT WATER TANK CAN BE DRAINED FROM THE FRONT OF THE MACHINE – UNPLUG MACHINE FROM POWER SOURCE. REMOVE POD WASTE TRAY. **CAUTION-UNLESS THE TANK IS LEFT TO COOL THE WATER IS EXTREMELY HOT AND CAN CAUSE HARMFUL BURNS.** REPLACE DRAIN PLUG, ENSURE HOSE CLAMP IS TIGHT AND REPOSITION DRAIN HOSE BEFORE RE-FILLING THE HOT WATER TANK.

Brewing Instructions for CX Touch W/QRC Option



Hold smart phone here to download & access menu.



On smart phone, choose & touch selection.





Choose Drink Strength and Cup Size. Touch "Next".



Point smart phone at QR code scanner. The pod door will open and pod holder will extend. Place pod in mechanism. Re-scan code to start brew cycle.




The brew cycle can be stopped by touching "CANCEL".




After the brew cycle is complete, the above screen will appear and remain for 2-minutes before returning to the blue QR screen.

To change from default "Combined" mode to "Touchless" only mode tap the **TEA & WATER** bar 3-times to access the **Programming** screen.

Touch to highlight the "Combined" box. Using the minus sign (-) tap until "ON" appears. If Touch only is desired, repeat the procedure and tap until "OFF" appears. Tap "Exit Setup Mode" when finished. Then tap "Exit Programming".



Upper Programming mode




Lower Programming mode

To get into the **Upper Programming** mode, tap the **upper left corner 3x** then the **lower right corner 3x**. **Lower Programming** mode: tap the **lower right corner 3x** only.




Machine Access Points




Pod Brew Mechanism Removal

Front View From Drip Tray




Front

View - Cover Off




Whipper Assembly PN 767377

ITEM #	PART NUMBER & DESCRIPTION
1	767376 WHIPPER STEAM CAP
2	767195 WHIPPER MOTOR
3	767196 BASE, WHIPPER MOUNTING
3.5	767390,O-RING WHIPPER BASE RED [NOT SHOWN]
4	767197 WHIPPER IMPELLER
5	767365 WHIPPER BOWL
6	767200 WHIPPER NOZZLE
7	781566 WHIPPER SEAL (<i>REPLACE AFTER 5000 CYCLES</i>)




Tank Assembly PN 780048



ITEM #	PART NUMBER	DESCRIPTION	QTY/EA
1	110958	RELAY, 12 VDC SPST 30A	1
2	111593	HI-LIMIT THERMOSTAT	1
3	109937	GEAR PUMP ASS'Y	1
4	781772	PUMP ASS'Y W/ELBOW (HOT WATER)	1
5	780253	TANK ONLY	1
6	773056	AIR PUMP, POD	1
7	500396	LIQUID LEVEL PROBE& BUSHING	2
8	151677	DUAL TEMP THERM PROBE	1
9	100149	ELBOW ¼ C X 1/8 NPT	1
10	704166-10 (1700W) 704161-10 (1400W)	TANK HEATING ELEMENT (US) TANK HEATING ELEMENT (CAN)	1
11	120682	FLOWMETER	1
12	767281	"WYE" HOSE FITTING	1
13	202165	AIR PUMP CHECK VALVE	1
14	202166	WATER PUMP CHECK VALVE	1


Whipper (767377) & Cannister (767385 & 767386) Assembly



ITEM #	PART NUMBER & DESCRIPTION
1	780796-HOPPER ASS'Y, RH (LATTE)
2	767202-ELBOW, 7CM,RH
3	767376-WHIPPER CAP
4	767365-BOWL, WHIPPER, 767197-IMPELLER
5	767196-WHIPPER BASE, 767195- MOTOR
6	767200-NOZZLE, WHIPPER
7	781040-BULKHEAD, WATER (NOT SHOWN)
8	767201-ELBOW, 7CM,LH
9	780197-HOPPER ASS'Y, LH (CHOCOLATE)
10	780153 -HOPPER LID-BROWN
11	780154-HOPPER LID-WHITE

61mm Pod Brew Mech Ass'y PN 780052

ITEM #	PART NUMBER	DESCRIPTION	QTY/EA
1	780230	BREW MECH MOTOR	2
2	780231	DELTROL SOLENOID	1
3	780553	LOWER BREW CHAMBER	1
4	773246	U-CUP SEAL RING	1
5	780257	UPPER BREW CHAMBER 61MM	1
6	780554	EJECT SLOPE CAM ASS'Y	1
7	780528	MOLDED BUMP DISC PAD	1
8	780422	1/4" X 3/16" NYLON SPACER	1
9	780546	KICKER SLIDE WASHER	1
10	780254	1/4" X 1" STAINLESS STANDOFF SPACER	1
11	780421	COMPRESSION SPRING	1
12	780264	LOWER BREW CHAMBER O-RING	1




NOTE: Your CX-3 can be equipped with various optional brew mechanisms to provide brewing choices tailored to your specific needs. For information on these optional brew mechanisms and associated replacement parts contact NEWCO Technical Services at 1-800-556-3926 or NEWCO Customer Service at 1-800-325-7867.

Wiring Diagram

782305 CONTROL BOARD ONLY

782306 CONTROL BOARD AND BRACKET ASS'Y



Left Blank Intentionally