

EASY-CLEAN

KEEP YOUR LIQUID COFFEE DISPENSER
CLEAN FOR BEST TASTING COFFEE & TEA

IMPROVE THE TASTE!

FOR USE WITH ALL BIB DISPENSERS

New from Newco, the leader in liquid coffee machines.

Ensure your coffee stays fresh and good tasting by using Easy-Clean, natural cleaning solution.

Cleaning liquid coffee dispensers is an essential part of preventative maintenance.

Easy-Clean keeps tubes and pumps running smoothly and free of bad tasting coffee residue.

Cleaner can be used in all liquid machines but coffee always tastes better out of a Newco machine!

Uses very little cleaner for each use.

Currently available with Scholle fitment or QCD fitment.

Customers can easily attach the cleaner to the tubes and simply prime the machine to clean.

Repeat sales with the cleaning solution.



PN: 900083

1 box with Scholle fitting

PN: 900084

1 box with QCD fitting



LIT PN:123107
ISSUED:012615
REVISED:051517

HOW-TO

Flushing Instructions:

1. Place Easy-Clean box into the BIB rack or compartment.
2. Pull Easy-Clean spout out through perforation.
3. Connect to beverage supply line.
4. Flush system for 2 minutes or until the solution runs clear.
[Agitate line to clear any syrup remaining in the line.]
5. Allow 2 minute rest cycle before reinstalling line to beverage BIB product.
6. Reinstall product line and refill with product.
7. Open dispensing valve until all cleaner dispenses and the syrup appears.



Remove product and place Easy-Clean box into the BIB compartment.



Pull spout out through box perforation and connect the beverage supply line.



Flush system for 2 minutes or until the discharged solution runs clear.



Close-up of QCD Fitting
PN: 400137



Easy Clean Flush for Scholle fitting 900083



Close-up of Scholle Fitting
PN: 107117



Easy Clean Flush Solution for QCD fitting 900084
(removed from the box view)

PREVENTIVE MAINTENANCE COMPONENTS:



PN: 107117
Scholle Connector (1)



PN: 400137
QCD Connector & Fitment (1)



PN: 120508
Clean Out Cap (1)



PN: 800013
Seat Cup [Faucet] (1)



PN:320282
Adaptor Flush QCD (1)



PN: 900083
Scholle

PN: 900084
QCD fitting

Note: Cleaning Adapters

Cleaning requires the use of a cleaning/flush adapter. An adapter may be purchased from Newco Enterprises, Inc. PN: 400137 for QCD cleaning/flush adapter. PN: 120508 for Scholle cleaning/flush adapter. A cleaning adapter can be made by taking an empty BIB bag and cutting away as much of the empty bag as possible. Wash the remaining connector and further trim off any remaining bag pieces if desired. This is now your cleaning adapter. It will allow the check valve in the connector to stay open during the cleaning process. Cleaning adapters may be saved for later use. You can also purchase premade cleaning solution that comes in a Bag-in-the-box that has either the Scholle or the QCD connector on it. PN: 900083, Cleaner "EASY CLEAN" [64 fluid ounces], with Scholle fitting. PN: 900084, Cleaner "Easy Clean" [64 fluid ounces] with QCD fitting.