## LARGE NO TOUCH HANDLE

ASSEMBLY INSTRUCTIONS



## TOUCHLESS



1.) Remove existing handle, bonnet, stem, spring and seat cup assembly by turning bonnet counterclockwise and pulling assembly from faucet.



**2.)** Remove existing handle by pushing up on seat cup with thumbs while pushing down on the bonnet and handle with fingers.



**3.)** Push handle forward and out of the groove by pushing forward with fingers.



**4.)** Install the no touch handle by placing it on the bonnet in front of the stem. Push up on the seat cup with your thumbs while pushing down on the handle and bonnet with fingers.



**5.)** Allign the pins on the handle with the grooves on the stem.



**6.)** Push the handle into the grooves with your fingers. Activate handle to make sure that it is locked into the stem grooves.

